

# inland

## MAGNASHIELD™

### User Instructions

The MagnaShield™ is an acrylic shield that provides added protection against grinder, shaper, and certain saw debris.

Please note that a MagnaShield™ is **not** intended to protect your eyes. Always wear complete eye protection whenever working with tools.

### Mounting Using the Wire Frame

The MagnaShield™ comes with a wire mounting bracket for use these current Inland machines:




no. 10030	<a href="#">Wizard IV Grinder</a>	no. 10650	<a href="#">SwapTop Grinder</a>
no. 20050	<a href="#">Impulse™</a>	no. 10640	<a href="#">SwapTop Hobby Shaper</a>
no. 20030	<a href="#">Wiz CG</a>	no. 10630	<a href="#">SwapTop Saw Wood Blade</a>
no. 2003_	Contour GT	no. 10660	<a href="#">SwapTop Saw Metal Blade</a>
no. 30050	<a href="#">Aero™</a>		
no. 30030	<a href="#">Wizling CG</a>		
no. 3003_	Contour		

To mount your MagnaShield™ place the ends of the wire mounting bracket into the two locator holes found on the rear of your machine. Set the plastic lens into position on the small wire loop on top. You can adjust the position slightly by bending the wire bracket to best suit your needs.

### Mounting Using the Post

You will need a plastic mounting post that fits into the grid surface if you plan to use this product on any of [Inland's older model machines](#) (pre-1991), including:



Wizard  
Wizard Plus

Wiz  
Wizling

PopTop Wiz  
PopTop Wizling

To receive a free plastic mounting post, call Inland Customer Service at 1-800-521-8428 or e-mail us at [helpdesk@inlandcraft.com](mailto:helpdesk@inlandcraft.com). To temporarily support your MagnaShield™ in one of these older style machines, you can insert the legs of the wire bracket into the far back corners of your open grid work surface.

Once you have the plastic mounting post, place the slotted end under running cold water for about 30 seconds. This will temporarily shrink the plastic and allow for easier insertion. Center the post directly behind the bit opening in the grid surface with the slotted opening lengthwise. Gently rock the mounting post while applying downward pressure until it is fully inserted into the holes in the grid surface. Set the plastic lens onto the peg end of the post.

### Maintenance

Clean your MagnaShield™ by removing it and rinse off under cool running water after every use. In order to prevent scratching, avoid rubbing or wiping the surface.

### Service

If you have any questions or comments regarding the use of this or any Inland product please call Inland Customer Service at 1-800-521-8428 9 AM to 5 PM EST, email us at [helpdesk@inlandcraft.com](mailto:helpdesk@inlandcraft.com), or write us at:

**Inland Craft Products, Co.**  
32052 Edward Dr.  
Madison Heights, MI 48071  
[www.inlandcraft.com](http://www.inlandcraft.com)